


EXPLODED VIEW NO. 1



LIST OF SPARE PARTS

PART. DESCRIPTION

- 1 LITTLE PIPE
- 2 DRAIN PIPE OF LEAKING
- 3 GASKET
- 4 PLASTIC BUSHING SUPPORT
- 5 BRASS BUSHING
- 8 COMPLETE MOTOR 220 V
- 8 COMPLETE MOTOR 240 V
- 8 COMPLETE MOTOR 110 V

PART. DESCRIPTION

- 9 MOTOR SUPPORT
- 10 DELRIN PART
- 11 CLIP
- 12 LATERAL MICROSWITCH
- 12 CENTRAL MICROSWITCH
- 13 STANDARD SPRING
- 13 SOFT SPRING
- 14 HOLDER RIGHT
- 14 HOLDER LEFT 3 CONTAINERS